LENMAR
BATTERY SOLUTIONS

NoMEM PRO
Nickel Metal-Hydride Battery System

NoMEM PRO Rechargeable NiMH Battery System
Get long lasting power for digital cameras and other high drain devices. Power that can give more that twice the photos per charge compared to standard alkaline batteries. Plus, they can recharged over and over, up to 1000 times. This is real power to save you hundreds of dollars compared to disposable batteries.

With NoMEM technology, the batteries can be recharged at any level and always ready to give you maximum performance.

- Recharges 2 or 4 AA/AAA NiMH or NiCd batteries.
- NiCd batteries charge in 1 hr. (700mAh), NiMH batteries in 2 hrs. (1600mAh).
- Built-in universal power supply (100-240VAC) uses switching technology for high efficiency, light weight.
- Microprocessor controlled for intelligent charging.
- Multiple safety systems for worry free use.
- LED indicators show Fast/Trickle Charge and Fault Condition status.
- Specially designed for rapid recharging of batteries for use in Digital Cameras, Handheld PC's, PDA's, FRS Radio's, etc.
- Includes 4 NoMEM PRO AA batteries using highest rated NiMH technology – up to twice the capacity of NiCd's.
  NoMEM technology – charge as often as you want – no memory effect.
- NoMEM PRO batteries are environmentally friendly – uses no toxic cadmium.

Lenmar is the Answer
The NoMEM PRO Battery System is another power solution from Lenmar, makers of innovative batteries,chargers, and accessories for camcorders, digital cameras, cellular phones, laptops and other portable electronics. For information, call 800-424-2703 or visit www.lenmar.com.

Instructions:
1. Open cover.
2. Charges 2 or 4 batteries only. If charging 2 batteries, install batteries only into 2 left or 2 right positions. Install batteries as shown (see diagram inside battery compartment).
   For AAA size batteries, flip down the (+) contacts by pulling down on the small

handle
at the top.

3. Flip out AC prongs and plug into AC outlet.
4. LED's are RED when charging, and GREEN when finished. Flashing LED shows bad battery, dispose and do not use. Once charge is finished, removed batteries and unplug charger.

Notes:

- Batteries are not charged as shipped. Must be charged prior to first use.
- Do Not mix NiCd and NiMH batteries together. Keep all NiMH batteries and NiCd batteries separate when charging or using.
- Charge only NiCd or NiMH batteries on this charger.
- Use only NoMEM PRO or other proper NiMH compatible charger to recharge NoMEM PRO batteries.
- Batteries may leak or explode causing personal injury if inserted improperly, disposed of in fire, mixed with other battery types, or short circuited.

This product carries a Two Year Limited Warranty. Send with proof of purchase and $7.50 for shipping and handling.

LENMAR ENTERPRISES, INC. USA
31328 Via Colinas, Suite 102
Westlake Village, CA 91362

Made in China